

## Notebooks, Netbooks and UMPCs

Green Text with Light Green Background indicates the adapter tip is included with Product.

Red Text with Clear Background indicates the adapter tip is sold separately.

N/A indicates that the adapter is not available or the Product is not compatible.

### Acer Aspire One

Model	MP3300	MP3450	MP3450i	MP3700	MP3750
Aspire One A110L, A110X	PA-N12	PA-N12	PA-N12	PA-N12	PA-N12
Aspire One A150, A150L, A150X, A150X-3G	PA-N12	PA-N12	PA-N12	PA-N12	PA-N12
Aspire One D150	PA-N12	PA-N12	PA-N12	PA-N12	PA-N12

### Acer Aspire

Model	MP3300	MP3450	MP3450i	MP3700	MP3750
2000, 2010, 2020, 2200 Series	PA-L5F	PA-L5F	PA-L5F	PA-L5F	PA-L5F
3000, 3500, 3600, 3610, 3624, 3630, 3680 Series	PA-L47	PA-L47	PA-L47	PA-L47	PA-L47
3020, 3025, 3040, 3620, 3690 Series	PA-L5F	PA-L5F	PA-L5F	PA-L5F	PA-L5F
5000, 5020, 5030, 5040, 5100, 5110, 5500, 5600, 5610, 5630, 5680, 5920, 7000, 7100 Series	PA-L5F	PA-L5F	PA-L5F	PA-L5F	PA-L5F
5010, 5012, 5014, 9800, 9805, 9810 Series	PA-L47	PA-L47	PA-L47	PA-L47	PA-L47
9100, 9300, 9410, 9420, 9500 Series	PA-L5F	PA-L5F	PA-L5F	PA-L5F	PA-L5F

### Acer Ferrari

Model	MP3300	MP3450	MP3450i	MP3700	MP3750
1000, 1004, 3000, 3200, 3400, 4000, 5000 Series	PA-L5F	PA-L5F	PA-L5F	PA-L5F	PA-L5F

### Acer TravelMate

Model	MP3300	MP3450	MP3450i	MP3700	MP3750
A550, A551, Alpha 550, Alpha 551 Series	PA-L5D	PA-L5D	PA-L5D	PA-L5D	PA-L5D
C100, C110, C200, C210, C300, C310 Series	PA-L47	PA-L47	PA-L47	PA-L47	PA-L47
200, 210, 212, 213, 220, 225, 230, 233, 260, 270, 272, 273, 280, 283 Series	PA-L5D	PA-L5D	PA-L5D	PA-L5D	PA-L5D
240, 243, 244, 250, 252, 253, 290, 291, 292, 293 Series	PA-L5F	PA-L5F	PA-L5F	PA-L5F	PA-L5F
530, 531, 533, 534, 535, 536 Series	PA-L5D	PA-L5D	PA-L5D	PA-L5D	PA-L5D
540, 541, 542, 543 Series	PA-L5F	PA-L5F	PA-L5F	PA-L5F	PA-L5F
600, 603, 610, 611, 612, 613, 614, 620, 630, 631, 650, 653, 654, 660 Series	PA-L5D	PA-L5D	PA-L5D	PA-L5D	PA-L5D
720, 722, 730, 732, 735, 739, 740, 800, 801, 802, 803, 804 Series	PA-L5D	PA-L5D	PA-L5D	PA-L5D	PA-L5D
2000, 2100, 2200, 2500, 2600, 2700 Series	PA-L5D	PA-L5D	PA-L5D	PA-L5D	PA-L5D
2300, 2310, 2350, 2400, 2420, 2450, 2480 Series	PA-L5F	PA-L5F	PA-L5F	PA-L5F	PA-L5F
3000, 3200, 3210, 3220, 3230, 3260 Series	PA-L47	PA-L47	PA-L47	PA-L47	PA-L47
5100, 5110, 5300, 5600, 5610, 5612, 6000, 6100, 6410, 6460, 6592 Series	PA-L5F	PA-L5F	PA-L5F	PA-L5F	PA-L5F
7000, 7100, 7300, 8000, 8100, 8200, 8204, 8205, 8210, 8215, 8216 Series	PA-L5F	PA-L5F	PA-L5F	PA-L5F	PA-L5F

### Apple

Model	MP3300	MP3450	MP3450i	MP3700	MP3750
PowerBook: 1400, 2400, 3400 Series	n/a	PA-N03	PA-N03	n/a	n/a
PowerBook: G3 Series	n/a	PA-N03	PA-N03	n/a	n/a

### ASUS Eee PC

Model	MP3300	MP3450	MP3450i	MP3700	MP3750
Eee PC 700, 900 Series	PA-L47	PA-L47	PA-L47	PA-L47	PA-L47
Eee PC 1000HA, 1000HD Series	PA-L47	PA-L47	PA-L47	n/a	PA-L47

### ASUS

Model	MP3300	MP3450	MP3450i	MP3700	MP3750
A6, A6JA, A6JC, A6K, A6KM, A6KT, A6R, A6V, A6VA, A6Vc, A6VM, A7S, A8, A8F Series	n/a	PA-L5F	PA-L5F	PA-L5F	PA-L5F
F3, F3P, F8, F9, F9F Series	n/a	PA-L5F	PA-L5F	PA-L5F	PA-L5F
G1 Series	n/a	PA-L5F	PA-L5F	PA-L5F	PA-L5F
M2000, M2000N, M6000N, M6700N, M6800N, M6B00N Series	n/a	PA-L5F	PA-L5F	PA-L5F	PA-L5F
M6N, M6V, M6VA, M9V, M50, M51, M70 Series	n/a	PA-L5F	PA-L5F	PA-L5F	PA-L5F
R1E, S6F, U3, U5A, U5F, U6E, U6S Series	n/a	PA-L5F	PA-L5F	PA-L5F	PA-L5F
V1, V1J, V2, V6, VX2, VX3 Series	n/a	PA-L5F	PA-L5F	PA-L5F	PA-L5F
W3000, W3, W3N, W3V, W5A, W5Ae, W5F, W5V, W7, W7J, Z35L Series	n/a	PA-L5F	PA-L5F	PA-L5F	PA-L5F

## Dell Inspiron

Model	MP3300	MP3450	MP3450i	MP3700	MP3750
1100 Series	PA-N07	PA-N07	PA-N07	n/a	n/a
1150, 1318, 1420 Series	n/a	PA-N11	PA-N11	PA-N11	PA-N11
1501, 1505, 1520, 1521, 1525 Series	n/a	PA-N11	PA-N11	PA-N11	PA-N11
1720, 1721 Series	n/a	PA-N11	PA-N11	PA-N11	PA-N11
4000, 4100, 4150, 4200, 5000, 5100, 5150 Series	PA-N07	PA-N07	PA-N07	n/a	n/a
6000, 6400 Series	n/a	PA-N11	PA-N11	PA-N11	PA-N11
7500, 8000, 8100, 8200 Series	PA-N07	PA-N07	PA-N07	n/a	n/a
8500, 8600, 9100, 9200, 9300, 9400 Series	n/a	PA-N11	PA-N11	PA-N11	PA-N11
300m, 500m, 600m, 630m, 640m, 700m, 710m Series	n/a	PA-N11	PA-N11	PA-N11	PA-N11
E1405, E1505, E1705 Series	n/a	PA-N11	PA-N11	PA-N11	PA-N11
Mini 9, Mini 10, Mini 12	n/a	PA-N12	PA-N12	n/a	PA-N12

## Dell Latitude

Model	MP3300	MP3450	MP3450i	MP3700	MP3750
CP, Cpi, CPt, CS, CPx Series	PA-N07	PA-N07	PA-N07	n/a	n/a
D400, D410, D420 Series	n/a	PA-N11	PA-N11	PA-N11	PA-N11
D500, D505, D510, D520, D531 Series	n/a	PA-N11	PA-N11	PA-N11	PA-N11
D600, D610, D620, D630, D631 Series	n/a	PA-N11	PA-N11	PA-N11	PA-N11
D800, D810, D820, D830 Series	n/a	PA-N11	PA-N11	PA-N11	PA-N11
X1, X300 Series	n/a	PA-N11	PA-N11	PA-N11	PA-N11

## Dell Precision

Model	MP3300	MP3450	MP3450i	MP3700	MP3750
M20 Series	n/a	PA-N11	PA-N11	PA-N11	PA-N11
M60, M65 Series	n/a	PA-N11	PA-N11	PA-N11	PA-N11
M70 Series	n/a	PA-N11	PA-N11	PA-N11	PA-N11

## Dell Vostro

Model	MP3300	MP3450	MP3450i	MP3700	MP3750
1000, 1400, 1500, 1700 Series	n/a	PA-N11	PA-N11	PA-N11	PA-N11

## Dell XPS

Model	MP3300	MP3450	MP3450i	MP3700	MP3750
M140 Series	n/a	PA-N11	PA-N11	PA-N11	PA-N11
M1210, M1330, M1530 Series	n/a	PA-N11	PA-N11	PA-N11	PA-N11

## Fujitsu LifeBook

Model	MP3300	MP3450	MP3450i	MP3700	MP3750
A4170, A4177, A4178, A4187, A4190 Series	PA-L5F	PA-L5F	PA-L5F	PA-L5F	PA-L5F
B2130, B2131, B2175, B2545, B2562, B2566, B2610, B2620, B2630 Series	PA-L65	PA-L65	PA-L65	PA-L65	PA-L65
B3000, B3000D, B3010D, B3020, B3020D Series	PA-L65	PA-L65	PA-L65	PA-L65	PA-L65
B6110D, B6210, B6220, B6230 Series	PA-L65	PA-L65	PA-L65	PA-L65	PA-L65
C2010, C2110, C2111, C2210, C2310, C2320, C2330 Series	PA-L5F	PA-L5F	PA-L5F	PA-L5F	PA-L5F
C-6581, C-6591, C-6611, C-6631, C-6651, C-7631, C-7651, C-7661 Series	PA-L65	PA-L65	PA-L65	PA-L65	PA-L65
E6550, E6555, E6556, E6557, E6570, E6571, E6575, E6595 Series	PA-L65	PA-L65	PA-L65	PA-L65	PA-L65
E6624, E6634, E6644, E6654, E6664, E6666 Series	PA-L5F	PA-L5F	PA-L5F	PA-L5F	PA-L5F
E7010, E7110, E8010, E8010D, E8020, E8020D, E8110, E8210, E8310 Series	PA-L5F	PA-L5F	PA-L5F	PA-L5F	PA-L5F
N3000, N3010, N3511, N3520, N3530 Series	PA-L5F	PA-L5F	PA-L5F	PA-L5F	PA-L5F
N5000, N5010, N6010, N6110, N6210, N6410, N6420 Series	PA-L5F	PA-L5F	PA-L5F	PA-L5F	PA-L5F
P1000, P1032, P1035, P1120, P1510, P1510D, P1610, P1620, P1630 Series	PA-L65	PA-L65	PA-L65	PA-L65	PA-L65
P5000, P5010, P5010D, P5020, P5020D, P7010, P7010D Series	PA-L65	PA-L65	PA-L65	PA-L65	PA-L65
P7120, P7120D, P7230, P7230D, P7230P, P8010, P8020 Series	PA-L65	PA-L65	PA-L65	PA-L65	PA-L65
Q2010 Series	PA-L65	PA-L65	PA-L65	PA-L65	PA-L65
S2010, S2020, S2110 Series	PA-L65	PA-L65	PA-L65	PA-L65	PA-L65
S2210 Series	PA-L5F	PA-L5F	PA-L5F	PA-L5F	PA-L5F
S6010, S6110, S6120, S6120D, S6210, S6220, S6231, S6240 Series	PA-L65	PA-L65	PA-L65	PA-L65	PA-L65
S6310, S6311, S6410 Series	PA-L5F	PA-L5F	PA-L5F	PA-L5F	PA-L5F
S7000, S7000D, S7010, S7010D, S7020, S7020B, S7020D, S7020E, S7021, S7025, S7110, S7111 Series	PA-L5F	PA-L5F	PA-L5F	PA-L5F	PA-L5F
T4010, T4010D Series	PA-L5F	PA-L5F	PA-L5F	PA-L5F	PA-L5F
T4210, T4215, T4220 Series	PA-L5F	PA-L5F	PA-L5F	PA-L5F	PA-L5F
U810, U820 Series	PA-L65	PA-L65	PA-L65	PA-L65	PA-L65

## Fujitsu Stylistic

Model	MP3300	MP3450	MP3450i	MP3700	MP3750
ST4110, ST4110P, ST4120, ST4120P, ST4121 Series	PA-L65	PA-L65	PA-L65	PA-L65	PA-L65
ST5000, ST5000D, ST5010, ST5010D, ST5011, ST5011D, ST5020, ST5020D, ST5021, ST5021D, ST5022, ST5022D, ST5030, ST5030D, ST5031, ST5031D, ST5032, ST5032D, ST5111, ST5112, ST6012 Series	PA-L65	PA-L65	PA-L65	PA-L65	PA-L65
T2010, T2020, T3010, T3010D Series	PA-L65	PA-L65	PA-L65	PA-L65	PA-L65

Gateway					
Model	MP3300	MP3450	MP3450i	MP3700	MP3750
400, 400L, 400S, 400SD4, 400SP, 400VTX, 400X, 400XL, 450, 450E, 450RGH, 450ROG, 450S, 450SP, 450SX4, 450X, 450XL Series	n/a	PA-L5F	PA-L5F	PA-L5F	PA-L5F
3000, 3018, 3018GZ, 3040, 3040GZ, 3500, 3520, 3520GZ, 3522GZ, 3525GB, 3525GZ, 3545, 3545GZ, 3550, 3550GH, 3550GZ, 3610GZ Series	n/a	PA-L5F	PA-L5F	PA-L5F	PA-L5F
4000, 4010, 4012, 4012GZ, 4014, 4014GB, 4016, 4024, 4024GZ, 4025, 4025GZ, 4026, 4026GZ, 4028, 4028GZ, 4028JP, 4030, 4030GH, 4030GZ Series	n/a	PA-L5F	PA-L5F	PA-L5F	PA-L5F
4520, 4520GZ, 4525, 4525GZ, 4528, 4528MX, 4530, 4530GH, 4530GZ, 4532, 4534, 4535, 4535GZ, 4536, 4536GZ, 4538, 4538GZ, 4540, 4540GZ, 4541, 4541BZ, 4542, 4542GP, 4543, 4543BZ Series	n/a	PA-L5F	PA-L5F	PA-L5F	PA-L5F
6000, 6010, 6010GZ, 6018, 6018GH, 6018GZ, 6018GX, 6020, 6020GZ, 6021, 6021GH, 6021GZ, 6022, 6022GZ, 6023, 6023GP, 6510, 6510GZ, 6518, 6518GZ, 6520, 6520GZ, 6525, 6525GP, 6530, 6531, 6531GZ Series	n/a	PA-L5F	PA-L5F	PA-L5F	PA-L5F
7000, 7110, 7110GX, 7210, 7210GX, 7215, 7215GX, 7300, 7305, 7305GZ, 7305GX, 7310, 7310MX, 7312, 7312MX, 7320, 7320GZ, 7322, 7322GZ, 7324, 7324GZ, 7325, 7325GZ, 7326, 7326GZ, 7330, 7330GH, 7330GZ, 7400, 7405, 7405GH, 7405GX, 7410, 7410GX, 7415, 7415GX, 7422, 7422GX, 7422GZ, 7426, 7426GX, 7430, 7430JP, 7500, 7508, 7508GX, 7510, 7510GX Series	n/a	PA-L5F	PA-L5F	PA-L5F	PA-L5F
CX200, CX200S, CX200X, CX210, CX210S, CX210X, CX2600, CX2608, CX2610, CX2615, CX2618, CX2619, CX2620, CX2620h, CX2700, CX2720, CX2724, CX2724h, CX2726, CX2728 Series	n/a	PA-L5F	PA-L5F	PA-L5F	PA-L5F
M210, M210CS, M210E, M210S, M210X, M210XL, M250, M250E, M250ES, M250A, M250B, M250G, M250GS, M250S, M250X, M255-E, M255-E SB, M255 G, M280, M280E, M280Eb, M280QS, M285-E, M285-E SB, M285 G Series	n/a	PA-L5F	PA-L5F	PA-L5F	PA-L5F
M305, M305CRV, M320, M320CS, M320E, M320S, M320X, M320XL, M325, M325X, M360, M360S, M360SB, M360SE, M360X, M360XL, M360A, M360B, M360C Series	n/a	PA-L5F	PA-L5F	PA-L5F	PA-L5F
M405, M460A, M460B, M460E, M460E Plus, M460ES, M460S, M460SX, M460S-QS, M460SX Series	n/a	PA-L5F	PA-L5F	PA-L5F	PA-L5F
M500, M500B1, M505, M505B2 Series	n/a	PA-L5F	PA-L5F	PA-L5F	PA-L5F
ML3000, ML3704, ML3706, ML6000, ML6219, ML6701, ML6703, ML6704, ML6704H Series	n/a	PA-L5F	PA-L5F	PA-L5F	PA-L5F
MT3000, MT3400, MT3418, MT3700, MT3705, MT3707 Series	n/a	PA-L5F	PA-L5F	PA-L5F	PA-L5F
MT6400, MT6451, MT6452, MT6456, MT6700, MT6704, MT6704H, MT6705, MT6707, MT6800, MT6821, MT6828, MT6828H Series	n/a	PA-L5F	PA-L5F	PA-L5F	PA-L5F
MX3000, MX3042, MX3044, MX3044H, MX3200, MX3210, MX3212, MX3215, MX3225, MX3228, MX3228H, MX3258, MX3258H, MX3558, MX3558H, MX3560, MX3560H, MX3562, MX3563, MX3563H, MX3600, MX3610 Series	n/a	PA-L5F	PA-L5F	PA-L5F	PA-L5F
MX6000, MX6025, MX6025H, MX6027, MX6027H, MX6028, MX6030, MX6121, MX6123, MX6124, MX6124H, MX6128, MX6135, MX6420, MX6421, MX6423, MX6424, MX6424H, MX6425, MX6428, MX6430, MX6433, MX6433H, MX6436, MX6437, MX6438, MX6440, MX6440H, MX6441, MX6442, MX6450, MX6453, MX6455 Series	n/a	PA-L5F	PA-L5F	PA-L5F	PA-L5F
MX6625, MX6627, MX6627H, MX6629, MX6629H, MX6631, MX6633, MX6633H, MX6640, MX6640B, MX6641, MX6641H, MX6650, MX6650H, MX6708, MX6708H, MX6710, MX6750, MX6912, MX6951, MX6951H, MX6958, MX6960 Series	n/a	PA-L5F	PA-L5F	PA-L5F	PA-L5F
MX8500, MX8520, MX8523, MX8525, MX8528, MX8530, MX8554B, MX8556F, MX8700, MX8710, MX8711 Series	n/a	PA-L5F	PA-L5F	PA-L5F	PA-L5F
NX100X, NX200, NX200S, NX200X, NX210, NX250, NX250X, NX260, NX260X, NX500, NX500S, NX500X, NX510, NX510S, NX510X, NX550, NX550X, NX550XL, NX560, NX560X, NX560XL, NX570, NX570QS, NX570X, NX570XL Series	n/a	PA-L5F	PA-L5F	PA-L5F	PA-L5F
NX860, NX860X, NX860XL Series	n/a	PA-L5F	PA-L5F	PA-L5F	PA-L5F
S-7200, S-7200C, S-7200N Series	n/a	PA-L5F	PA-L5F	PA-L5F	PA-L5F
X2620H Series	n/a	PA-L5F	PA-L5F	PA-L5F	PA-L5F

Gateway Solo					
Model	MP3300	MP3450	MP3450i	MP3700	MP3750
1100, 1150, 1200, 1400, 1450 Series	n/a	PA-L5F	PA-L5F	PA-L5F	PA-L5F
2000, 2100, 2150, 2200, 2300, 2300LS, 2300XL, 2500, 2500LS, 2500SE, 2500XL, 2550, 2551 Series	n/a	PA-L5F	PA-L5F	PA-L5F	PA-L5F
5000, 5100, 5100XL, 5150LS, 5150SE, 5150XL, 5300, 5300CS, 5300L, 5300LS, 5350 Series	n/a	PA-L5F	PA-L5F	PA-L5F	PA-L5F
9100, 9100LS, 9100SE, 9100XL, 9150, 9300, 9300CX, 9300VE, 9300XL Series	n/a	PA-L5F	PA-L5F	PA-L5F	PA-L5F

<b>HP</b>					
Model	MP3300	MP3450	MP3450i	MP3700	MP3750
Mini 1000, Mini 1033	n/a	PA-L42	PA-L42	PA-L42	PA-L42
2133 Mini-Note PC	n/a	PA-N10	PA-N10	PA-N10	PA-N10
Mini 2140 Notebook PC	n/a	PA-N10	PA-N10	PA-N10	PA-N10
2533t Mobile Thin Client	n/a	PA-N10	PA-N10	PA-N10	PA-N10
510, 530, 550 Notebook PC	n/a	PA-N10	PA-N10	PA-N10	PA-N10

<b>HP EliteBook</b>					
Model	MP3300	MP3450	MP3450i	MP3700	MP3750
2530p, 2730p Notebook PC	n/a	PA-N10	PA-N10	PA-N10	PA-N10
6930p, 8530p Notebook PC	n/a	PA-N10	PA-N10	PA-N10	PA-N10

<b>HP / Compaq</b>					
Model	MP3300	MP3450	MP3450i	MP3700	MP3750
2230s, 2510p, 2710p Notebook PC	n/a	PA-N10	PA-N10	PA-N10	PA-N10
6510b, 6515b, 6530b, 6535b, 6710b, 6715b, 6720s	n/a	PA-N10	PA-N10	PA-N10	PA-N10
6720t Mobile Thin Client	n/a	PA-N10	PA-N10	PA-N10	PA-N10
6730b, 6730s, 6735b, 6735s, 6820s, 6830s, 6910p Notebook PC	n/a	PA-N10	PA-N10	PA-N10	PA-N10
8510p, 8710p Notebook PC	n/a	PA-N10	PA-N10	PA-N10	PA-N10
Mini 2140 Notebook PC	n/a	PA-N10	PA-N10	PA-N10	PA-N10
NC2400, NC4010, NC4200, NC4400 Notebook PC	n/a	PA-N10	PA-N10	PA-N10	PA-N10
NC6120, NC6140, NC6220, NC6230, NC6320, NC6400 Notebook PC	n/a	PA-N10	PA-N10	PA-N10	PA-N10
NC8430 Notebook PC	n/a	PA-N10	PA-N10	PA-N10	PA-N10
NX6110, NX6115, NX6325, NX7300, NX7400, NX9420 Notebook PC	n/a	PA-N10	PA-N10	PA-N10	PA-N10
TC4200, TC4400 Tablet PC	n/a	PA-N10	PA-N10	PA-N10	PA-N10

<b>HP / Compaq Pavilion</b>					
Model	MP3300	MP3450	MP3450i	MP3700	MP3750
DV1000, DV2000, DV4000, DV5000z, DV6000, DV8000 Series	n/a	PA-L5F	PA-L5F	PA-L5F	PA-L5F
DV9000, DV9500 Series	n/a	PA-N01	PA-N01	PA-N01	PA-N01
DV4, DV4t, DV4z Series	n/a	PA-N10	PA-N10	n/a	n/a
TX1000, TX2000 Series	n/a	PA-L47	PA-L47	PA-L47	PA-L47
ZE2000, ZE4000, ZE4100, ZE4200, ZE4300, ZE4400, ZE4500, ZE4600, ZE4700, ZE4800, ZE4900, ZE5000 Series	n/a	PA-L5F	PA-L5F	PA-L5F	PA-L5F
ZT3000 Series	n/a	PA-L5F	PA-L5F	PA-L5F	PA-L5F
ZT3100, ZT3200, ZT3300, ZT3400 Series	n/a	PA-N01	PA-N01	PA-N01	PA-N01

<b>HP / Compaq Presario</b>					
Model	MP3300	MP3450	MP3450i	MP3700	MP3750
2100, 2200, 2500 Series	n/a	PA-L5F	PA-L5F	PA-L5F	PA-L5F
C500T Series	n/a	PA-L5F	PA-L5F	PA-L5F	PA-L5F
F750 Series	n/a	PA-N01	PA-N01	PA-N01	PA-N01
M2000 Series	n/a	PA-L5F	PA-L5F	PA-L5F	PA-L5F
R4000 Series	n/a	PA-N01	PA-N01	PA-N01	PA-N01
V2000, V3000, V4000, V5000, V6000 Series	n/a	PA-L5F	PA-L5F	PA-L5F	PA-L5F
X1000 Series	n/a	PA-L5F	PA-L5F	PA-L5F	PA-L5F
X1200, X1300, X1400, X1500 Series	n/a	PA-N01	PA-N01	PA-N01	PA-N01

<b>HTC</b>					
Model	MP3300	MP3450	MP3450i	MP3700	MP3750
Shift X9500	PA-L5D	PA-L5D	PA-L5D	PA-L5D	PA-L5D

<b>Kohjinsha</b>					
Model	MP3300	MP3450	MP3450i	MP3700	MP3750
SA series	PA-L5F	PA-L5F	PA-L5F	PA-L5F	PA-L5F
SH series	PA-L5F	PA-L5F	PA-L5F	PA-L5F	PA-L5F
SR series	PA-L5F	PA-L5F	PA-L5F	PA-L5F	PA-L5F

<b>Lenovo IdeaPad</b>					
Model	MP3300	MP3450	MP3450i	MP3700	MP3750
S9, S9e Series	n/a	PA-S5F	PA-S5F	PA-S5F	PA-S5F
S10, S10e Series	n/a	PA-S5F	PA-S5F	PA-S5F	PA-S5F
S10-2 Series	n/a	PA-S5F	PA-S5F	PA-S5F	PA-S5F

## Lenovo / IBM ThinkPad

Model	MP3300	MP3450	MP3450i	MP3700	MP3750
A20m, A20p, A21e, A21m, A21p, A22e, A22m, A22p, A30, A30p, A31, A31p Series	n/a	PA-L5F	PA-L5F	PA-L5F	PA-L5F
R30, R31, R32, R40, R40e, R50, R50e, R50p, R51, R51e, R52 Series	n/a	PA-L5F	PA-L5F	PA-L5F	PA-L5F
R60, R60e, R61, R61i, R61e Series	n/a	PA-N09	PA-N09	PA-N09	PA-N09
R400, R500 Series	n/a	PA-N09	PA-N09	PA-N09	PA-N09
SL300, SL400, SL500 Series	n/a	PA-N09	PA-N09	PA-N09	PA-N09
T20, T21, T22, T23, T30, T40, T40p, T41, T41p, T42, T42p, T43, T43p Series	n/a	PA-L5F	PA-L5F	PA-L5F	PA-L5F
T60, T60p, T61 Series	n/a	PA-N09	PA-N09	PA-N09	PA-N09
T400, T500, W500 Series	n/a	PA-N09	PA-N09	PA-N09	PA-N09
X20, X21, X22, X23, X24, X30, X31, X40, X41, X41 Tablet Series	n/a	PA-L5F	PA-L5F	PA-L5F	PA-L5F
X60, X60s, X61, X61s, X61s Series	n/a	PA-N09	PA-N09	PA-N09	PA-N09
X200, X300 Series	n/a	PA-N09	PA-N09	PA-N09	PA-N09
Z60, Z60m, Z60t, Z61p Series	n/a	PA-N09	PA-N09	PA-N09	PA-N09

## Lenovo / IBM 3000

Model	MP3300	MP3450	MP3450i	MP3700	MP3750
C100, C200 Series	n/a	PA-N09	PA-N09	PA-N09	PA-N09
N100, N200 Series	n/a	PA-N09	PA-N09	PA-N09	PA-N09
V100, V200 Series	n/a	PA-N09	PA-N09	PA-N09	PA-N09

## Neoware

Model	MP3300	MP3450	MP3450i	MP3700	MP3750
M100	n/a	PA-L5F	PA-L5F	PA-L5F	PA-L5F

## OQO

Model	MP3300	MP3450	MP3450i	MP3700	MP3750
Model 02	PA-CLA	PA-CLA	PA-CLA	PA-CLA	PA-CLA

## Panasonic Toughbook

Model	MP3300	MP3450	MP3450i	MP3700	MP3750
CF-08, CF-18, CF-19	n/a	PA-S5F	PA-S5F	PA-S5F	PA-S5F
CF-R3, CF-R4, CF-R4, CF-R5, CF-R6, CF-R7	n/a	PA-S5F	PA-S5F	PA-S5F	PA-S5F
CF-T1, CF-T2, CF-T4, CF-T5, CF-T7	n/a	PA-S5F	PA-S5F	PA-S5F	PA-S5F
CF-W2, CF-W4, CF-W5, CF-W7	n/a	PA-S5F	PA-S5F	PA-S5F	PA-S5F
CF-Y2, CF-Y4, CF-Y5, CF-Y7	n/a	PA-S5F	PA-S5F	PA-S5F	PA-S5F

## Samsung

Model	MP3300	MP3450	MP3450i	MP3700	MP3750
NC10, NC20 mini notebook	n/a	PA-L55	PA-L55	PA-L55	PA-L55
N110 Series	n/a	PA-L55	PA-L55	PA-L55	PA-L55
NP-P200	n/a	PA-L55	PA-L55	PA-L55	PA-L55
P460, P560 Series	n/a	PA-L55	PA-L55	PA-L55	PA-L55
Q1, Q1EX, Q1U Series	PA-L55	PA-L55	PA-L55	PA-L55	PA-L55
Q310 Series	n/a	PA-L55	PA-L55	PA-L55	PA-L55
R610 Series	n/a	PA-L55	PA-L55	PA-L55	PA-L55
X360, X460 Series	n/a	PA-L55	PA-L55	PA-L55	PA-L55

## Sony Vaio

Model	MP3300	MP3450	MP3450i	MP3700	MP3750
PCG-700, PCG-800 Series	n/a	PA-L65	PA-L65	PA-L65	PA-L65
UX180P	n/a	PA-L65	PA-L65	PA-L65	PA-L65
VGN-AR290G	n/a	n/a	n/a	n/a	n/a
VGN-BX670, VGN-BX675 Series	n/a	PA-L65	PA-L65	PA-L65	PA-L65
VGN-C140, VGN-C150, VGN-C190, VGN-C210, VGN-C220, VGN-C240, VGN-C250, VGN-C260, VGN-C290 Series	n/a	PA-L65	PA-L65	PA-L65	PA-L65
VGN-CR240, VGN-290, VGN-CR305, VGN-CR390, VGN-CR490, VGN-CR590, VGN-CS190, VGN-CS290 Series	n/a	PA-L65	PA-L65	PA-L65	PA-L65
VGN-FE550, VGN-FE570, VGN-FE590, VGN-FE600, VGN-FE650, VGN-FE660, VGN-FE670, VGN-FE680, VGN-FE690 Series	n/a	PA-L65	PA-L65	PA-L65	PA-L65
VGN-FE770, VGN-FE780, VGN-FE790, VGN-FE855, VGN-FE870, VGN-FE880, VGN-FE890 Series	n/a	PA-L65	PA-L65	PA-L65	PA-L65
VGN-FS500, VGN-FS520, VGN-FS530, VGN-FS540, VGN-FS550, VGN-FS550, VGN-FS570 Series	n/a	PA-L65	PA-L65	PA-L65	PA-L65
VGN-FS620, VGN-FS630, VGN-FS640, VGN-FS650, VGN-FS660, VGN-FS670, VGN-FS680, VGN-FS690 Series	n/a	PA-L65	PA-L65	PA-L65	PA-L65
VGN-FS710, VGN-FS720, VGN-FS730, VGN-FS740, VGN-FS750, VGN-FS760, VGN-FS770, VGN-FS780, VGN-FS790 Series	n/a	PA-L65	PA-L65	PA-L65	PA-L65
VGN-FS810, VGN-FS830, VGN-FS840, VGN-FS850, VGN-FS875, VGN-FS900 Series	n/a	PA-L65	PA-L65	PA-L65	PA-L65
VGN-FS920, VGN-FS940, VGN-FS950, VGN-FS960, VGN-FS970, VGN-FS980, VGN-FS990 Series	n/a	PA-L65	PA-L65	PA-L65	PA-L65
VGN-FW290 Series	n/a	PA-L65	PA-L65	PA-L65	PA-L65
VGN-FZ130, VGN-FZ140, VGN-FZ150, VGN-FZ160, VGN-FZ180, VGN-FZ190 Series	n/a	PA-L65	PA-L65	PA-L65	PA-L65
VGN-N110, VGN-N120, VGN-N130, VGN-N150, VGN-N160, VGN-N170, VGN-N220, VGN-N230, VGN-N250, VGN-N270, VGN-N320, VGN-N330, VGN-N370 Series	n/a	PA-L65	PA-L65	PA-L65	PA-L65
VGN-NS190, VGN-NS235, VGN-NS290 Series	n/a	PA-L65	PA-L65	PA-L65	PA-L65
VGN- P530H, VGN-P588E, VGN-P598E Series	PA-L47	PA-L47	PA-L47	PA-L47	PA-L47
VGN-S380, VGN-S430, VGN-S460, VGN-S470, VGN-S480, VGN-S550, VGN-S560, VGN-S570, VGN-S580, VGN-S660 Series	n/a	PA-L65	PA-L65	PA-L65	PA-L65
VGN-SR290 Series	n/a	PA-L65	PA-L65	PA-L65	PA-L65
VGN-SZ210, VGN-SZ220, VGN-SZ230, VGN-SZ240, VGN-SZ250, VGN-SZ260, VGN-SZ270, VGN-SZ280 Series	n/a	PA-L65	PA-L65	PA-L65	PA-L65
VGN-SZ320, VGN-SZ330, VGN-SZ340, VGN-SZ360, VGN-SZ370, VGN-SZ380, VGN-SZ390 Series	n/a	PA-L65	PA-L65	PA-L65	PA-L65
VGN-SZ430, VGN-SZ440, VGN-SZ450, VGN-SZ460, VGN-SZ470, VGN-SZ480, VGN-SZ491, VGN-SZ640, VGN-SZ650, VGN-SZ670 Series	n/a	PA-L65	PA-L65	PA-L65	PA-L65
VGN-SZ691, VGN-SZ750, VGN-SZ770, VGN-SZ791 Series	n/a	PA-L65	PA-L65	PA-L65	PA-L65
VGN-TXN25N/B Series	n/a	PA-L65	PA-L65	PA-L65	PA-L65

## Toshiba Portege

Model	MP3300	MP3450	MP3450i	MP3700	MP3750
2000, 2010, 3500, 3505, 4000, 4005, 4010 Series	PA-L63	PA-L63	PA-L63	PA-L63	PA-L63
7000CT, 7010CT, 7020CT, 7140CT, 7200CT/Cte, 7220Cte Series	PA-L63	PA-L63	PA-L63	PA-L63	PA-L63
M100, M200, M205, M300, M400, M405, M700, M705 Series	PA-L63	PA-L63	PA-L63	PA-L63	PA-L63
R100, R200, R400, R500, S100 Series	PA-L63	PA-L63	PA-L63	PA-L63	PA-L63

<b>Toshiba Qosmio</b>					
Model	MP3300	MP3450	MP3450i	MP3700	MP3750
E15, F15, F25, F45 Series	n/a	PA-L63	PA-L63	PA-L63	PA-L63
G15, G25, G35, G45 Series	n/a	n/a	n/a	n/a	n/a
X305	n/a	n/a	n/a	n/a	n/a

<b>Toshiba Satellite</b>					
Model	MP3300	MP3450	MP3450i	MP3700	MP3750
1400, 1405, 1410, 1415, 1800, 1805 Series	PA-L63	PA-L63	PA-L63	PA-L63	PA-L63
2060, 2100, 2140XCDS, 2180CDT, 2210CDT/XCDS, 2230, 2250, 2400, 2405, 2410, 2415, 2505CDS, 2510, 2520, 2530, 2540, 2550, 2590CDT/CDS/CDT/XDVD, 2610, 2615DVD, 2650, 2655XDVD, 2670, 2710, 2740, 2750, 2770, 2800/2805 Series	PA-L63	PA-L63	PA-L63	PA-L63	PA-L63
3000, 3005 Series	n/a	PA-L63	PA-L63	PA-L63	PA-L63
4000CDS/CDT, 4005CDS/CDT, 4010CDS/CDT, 4015CDS/CDT, 4020CDT, 4025CDT, 4030CDT, 4060, 4070, 4080CDT, 4090XDVD, 4100XDVD Series	PA-L63	PA-L63	PA-L63	PA-L63	PA-L63
5000, 5005, 5105, 5200, 5205 Series	PA-L63	PA-L63	PA-L63	PA-L63	PA-L63
A10, A15, A30, A35, A50, A55, A60, A65, A70, A75, A80, A85 Series	n/a	PA-L63	PA-L63	PA-L63	PA-L63
A20, A25, A40, A45 Series	n/a	n/a	n/a	n/a	n/a
A100, A105, A110, A130, A135 Series	n/a	PA-L63	PA-L63	PA-L63	PA-L63
A200, A205, A215 Series	n/a	PA-L63	PA-L63	PA-L63	PA-L63
L10, L15, L20, L25, L35, L45 Series	n/a	PA-L63	PA-L63	PA-L63	PA-L63
M20, M30, M35, M40, M45, M50, M55, M60, M65 Series	n/a	PA-L63	PA-L63	PA-L63	PA-L63
M100, M105, M110, M115 Series	n/a	PA-L63	PA-L63	PA-L63	PA-L63
M200, M205 Series	n/a	PA-L63	PA-L63	PA-L63	PA-L63
P10, P15, P30, P35 Series	n/a	PA-L63	PA-L63	PA-L63	PA-L63
P100, P105 Series	PA-L63	PA-L63	PA-L63	PA-L63	PA-L63
P100-ST9xxx, P105-S921, P105-S9xxx Series	n/a	n/a	n/a	n/a	n/a
P200, P205 Series	n/a	PA-L63	PA-L63	PA-L63	PA-L63
R10, R15, R20, R25 Series	PA-L63	PA-L63	PA-L63	PA-L63	PA-L63
U200, U205 Series	PA-L63	PA-L63	PA-L63	PA-L63	PA-L63
U300, U305 Series	n/a	PA-L63	PA-L63	PA-L63	PA-L63

<b>Toshiba Satellite Pro</b>					
Model	MP3300	MP3450	MP3450i	MP3700	MP3750
430, 440, 450, 460, 470, 480, 490 Series	PA-L63	PA-L63	PA-L63	PA-L63	PA-L63
4280ZDVD, 4220, 4260DVD, 4280XDVD, 4300, 4600 Series	PA-L63	PA-L63	PA-L63	PA-L63	PA-L63
6000, 6100 Series	PA-L63	PA-L63	PA-L63	PA-L63	PA-L63
A200, A210 Series	n/a	PA-L63	PA-L63	PA-L63	PA-L63
M10, M15 Series	PA-L63	PA-L63	PA-L63	PA-L63	PA-L63
S300, S300M Series	PA-L63	PA-L63	PA-L63	PA-L63	PA-L63

<b>Toshiba Tecra</b>					
Model	MP3300	MP3450	MP3450i	MP3700	MP3750
8000, 8100, 8200, 9000, 9100 Series	PA-L63	PA-L63	PA-L63	PA-L63	PA-L63
A1, A2, A3, A4, A5, A8, A9, A10 Series	PA-L63	PA-L63	PA-L63	PA-L63	PA-L63
M1, M2, M2V, M3, M4, M5, M6, M7, M8, M9, M10 Series	PA-L63	PA-L63	PA-L63	PA-L63	PA-L63
R10, S1, S2, S3 Series	PA-L63	PA-L63	PA-L63	PA-L63	PA-L63
TE2000, TE2100, TE2300 Series	PA-L63	PA-L63	PA-L63	PA-L63	PA-L63